



# Status Field Codes

The status field is an optional single character field that distinguishes the data contained on the layer according to the status of the work or the construction phase. The prescribed field codes for this field are as follows:

Code	Status
A	Abandoned
D	Existing to demolish
E	Existing to remain
F	Future work
M	Items to be moved
N	New work
S	Surveyed
T	Temporary work
X	Not in contract
1-9	Phase numbers